









RESIDENTIAL WATER HEATER PARTS LIST  
MODELS GPSX - 50  
100/101 SERIES



**A.O. Smith Water Heater Parts Fulfillment**  
125 Southeast Parkway  
Franklin, TN 37068  
1-800-433-2545  
www.hotwater.com

Item	Description	
1	Anode - Aluminum (.750" dia.) Standard Models	183523-29
1	Anode - Magnesium (.840" dia.) Optional	183463-38
<b>BAFFLE</b>		
2	Flue Baffle Assembly with Plate	184688-000
3	Hanger, Flue Baffle	181360-002
4	Restrictor, Flue Baffle	034894-000
5	<b>BLOWER ASSEMBLY</b>	<u>182379-001</u>
6	Adapter	182918
7	Gasket	181765
8	Gasket, Tee	182278
9	*Switch, Thermostat	183380
10	Tee Assembly	182240-2
11	Pressure Switch	- - -
12	<b>BURNER ASSEMBLY - NATURAL 100 Series</b>	184058-000
12	<b>BURNER ASSEMBLY - PROPANE 101 Series</b>	184060-000
13	Burner Head - Natural	181970
13	Burner Head - Propane	183220
14	Ignitor, Hot Surface - Natural	<u>185486-000</u>
14	Ignitor, Hot Surface - Propane	<u>185148-000</u>
15	Orifice, Main - Natural	181508-24
15	Orifice, Main - Propane	181791-44
16	Tube, Main Burner - Natural	184057-000
16	Tube, Main Burner - Propane	184932-008
17	Collar, Pipe	020172-21
<b>DOOR</b>		
18	Inner	183491
19	Outer	180522-000
20	Dirt Leg Assembly (Not Factory Supplied)	181206-1
<b>ENVELOPE WITH PARTS</b>		
21	Plate, Wall 2"	182787
22	Plate, Wall 3"	181557
23	Terminal, Vent 2"	183006
24	Terminal, Vent 3"	192815
25	Rubber Coupling w/Clamps	182933
26	<b>HARNES W/CLIPS</b>	183090-1
27	Clip, Wiring Harness	183365
28	Harness, Wiring	183510-1
29	*Instruction Manual	184676-000
30	Insulation, T & P Valve	183256
31	Insulation, Pipe 24"	181639-003
<b>LABELS</b>		
32	Scald Warning / Flammable Vapors	183301
33	Lighting & Operating	183764
34	Tube, Inlet Polypropylene w/Spacer (Standard)	183359-41
35	Spacer, Inlet Tube (Supplied with Item 34)	183706
36	Valve, Drain - Nylon (Optional)	42037-1
37	Valve, Drain - Brass (Standard)	26273-4
38	Valve, Main Gas Shutoff	181737
39	Valve, Combination Control - Natural	<u>183760-2</u>
40	Valve, Combination Control - Propane	<u>183760-3</u>
41	Valve, T & P	<u>043151-004</u>

**NOTE:** Underlined parts are recommended stock items for emergency replacement.

Consider gas used in your area only.

\* Not illustrated.